

MOUNTING INSTRUCTIONS



Thank you for choosing this quality product from Desert Fox.

It has been designed by passionate bikers, for bikers.

The Sahara has been produced from high-tenacity 1680 D ballistic nylon.

Ballistic nylon refers to a very specific type of nylon fabric weave that has been engineered for unrivalled abrasion & tear resistance.

In fact, its original intended purpose was for the protection of aircraft personnel to protect them from shrapnel and other debris that were the result of gunfire, artillery shell explosions and other ballistic impacts, hence the name.

You can be rest assured you have one of the toughest fabrics available.

We wish you many happy miles!

When installing the saddlebags there are a couple very important things to take note of:

- 1 Make sure the bags are firmly secured over the rear seat and are flat against your pannier frames.

This is done by adjusting the Velcro seat straps until the saddlebags are snug against the pannier frames.

- ! The bags must not touch the exhaust.

② REAR OF PANNIER

Loop the included strap around **the rear** of the pannier frame and then:

- through the steel rings (A) on the rear of the panniers
- through the openings behind the side pockets (B)



③ FRONT OF PANNIER

Loop the strap through the side pocket openings & steel rings (C)

- Tension strap (D)
- Cable security lock (E) - place cable through seat strap and pannier frame. Tension and lock.

